

# Step-by-Step Installation Guide for 5MWh All-in-One BESS at Telecom Sites

2025-03-19 10:24

## From Blueprint to Power: A Real-World Guide to Installing a 5MWh BESS for Telecom

Hey there. Let's talk about something that keeps me up at night, and probably keeps you up too if you're responsible for powering critical infrastructure like telecom base stations. It's not just about having a battery backup; it's about deploying a massive, utility-scale 5-megawatt-hour system reliably, safely, and without blowing the budget or the schedule. I've been on more muddy sites and concrete pads than I can count, and honestly, the difference between a smooth rollout and a costly nightmare often comes down to the installation process itself.

### Quick Navigation

- [The Real Problem: It's More Than Just a Big Battery](#)
- [Phase 1: Site Prep is Everything](#)
- [Phase 2: The Art of Unpacking & Commissioning](#)
- [The Heart of the Matter: Thermal Management & C-Rate](#)
- [Final Thoughts You'd Expect on Our Experience](#)

### The Real Problem: It's More Than Just a Big Battery


We all see the headlines about the need for grid resilience and backup power, especially for telecom. But the gap between buying a containerized BESS and having it actually, reliably online is huge. The pain isn't in the concept; it's in the execution. I've seen firsthand on site how projects get derailed: unexpected civil work costs, integration headaches with existing power equipment, and the constant, gnawing worry about long-term safety and degradation. You're not just installing a product; you're installing a 20-year asset that needs to perform from day one.

Let's agitate that a bit. According to the [National Renewable Energy Laboratory \(NREL\)](#), balance-of-system (BOS) and soft costs which include installation, permitting, and engineering can make up a staggering 30-50% of the total capital expenditure for a large-scale BESS. That's where budgets bleed. A misstep in the install phase doesn't just mean a delay; it directly hits your project's Levelized Cost of Energy (LCOE), the ultimate metric for whether this storage makes financial sense over its lifetime.

### Phase 1: Site Prep is Everything (Weeks 1-2)

This is where the coffee gets strong. The all-in-one, pre-integrated 5MWh unit from Highjoule is designed to simplify things, but it's not magic. It needs a proper home.

- **The Pad:** This isn't your average concrete slab. We're talking about a reinforced, perfectly level foundation designed for a 40+ ton container, with specific anchor points and often, seismic considerations depending on the region (California's Title 24, I'm looking at you). Getting the civil engineering wrong here is a show-stopper.
- **Utility Interconnection Point:** Knowing exactly where your medium-voltage hookup is, and having the switchgear ready, saves days of frantic scrambling. I've watched crews wait for the utility to show up because this wasn't crystal clear in week one.
- **Safety & Compliance Perimeter:** Before the container even ships, we mark out safety zones, fire access routes, and signage locations. For our projects in the US, this means pre-aligning with UL 9540 and NFPA 855 standards. In Europe, it's IEC 62933 and local fire safety codes. Doing this upfront avoids costly rework later.





## Phase 2: The Art of Unpacking & Commissioning (Weeks 3-4)

The truck arrives. Here's where an integrated system proves its worth. With a traditional setup, you'd have multiple containers for batteries, power conversion systems (PCS), and cooling. Ours is one. That means one crane lift, one set of connections.

The step-by-step looks like this:

1. Placement & Anchoring: Precision drop onto the pad. Bolt-down using seismic-grade anchors. This is a one-chance operation.
2. Electrical Hookup: Connecting the main AC cables from the grid interconnect to our built-in PCS. Then, the DC busbars inside the container are already pre-connected to the battery racks a massive time-saver we designed in to reduce on-site labor and fault points.
3. Commissioning & "First Juice": This is the moment of truth. We power up the control systems and run a meticulous sequence: insulation resistance tests, communication checks with the base station's load controllers, and finally, a controlled first charge/discharge cycle. We're not just turning it on; we're teaching the system about its new environment and verifying every safety protocol, from the cell-level BMS up to the grid interface.

## The Heart of the Matter: Thermal Management & C-Rate

Let me geek out for a second on something critical. When we talk about a 5MWh system, we have to talk about C-rate basically, how fast you charge or discharge it. A telecom base station might need a high burst of power (a high C-rate) during a grid outage. But pushing lithium-ion batteries too hard generates heat. If that heat isn't managed, degradation accelerates, and safety risks increase.

That's why our integrated design pairs a specific C-rate capability with a liquid cooling system that's calibrated for it. The cooling loops are built-in and pre-tested. On site, we just connect the external dry cooler. This isn't an afterthought; it's core to ensuring the system delivers its promised cycle life and maintains safety, which is non-negotiable for a remote, unattended site. Poor thermal management is a silent LCOE killer.

## A Case from the Field: Northern Germany

Let me give you a real example. We deployed a system for a major telecom operator in Schleswig-Holstein. The challenge? The site was remote, space was tight, and local regulations required strict adherence to German VDE standards (based on IEC).

The all-in-one format was a lifesaver. The pre-certified container passed local inspector reviews quickly because everything—battery modules, PCS, fire suppression, and cooling—was a validated unit under one certification. The step-by-step install, which we planned jointly with the client's local engineering firm, took just under four weeks from pad-ready to grid-sync. The key was that 90% of the complex integration work happened in our factory, not in a windy field in Germany. Today, that system provides critical backup during grid instability and allows the operator to participate in local energy markets, improving their overall economics.



### Final Thoughts: Your Project, Our Experience

Look, at Highjoule, we've built our reputation over nearly two decades not just on the technology inside the container, but on the process of getting it working for you. The step-by-step installation guide we follow is born from scars and successes on five continents. It's about reducing your BOS costs, mitigating risk, and ensuring that when you flip the switch, the system delivers for decades.

So, what's the biggest hurdle you're anticipating for your next utility-scale storage deployment? Is it the site logistics, the local permitting maze, or the long-term performance guarantees? Let's chat.

Author: Thomas Han

12+ years agricultural energy storage engineer / Highjoule CTO

URL: <https://glenproperty.co.za/articles/step-by-step-installation-of-all-in-one-integrated-5mwh-utility-scale-bess-for-telecom-base-stations>